RLH012A500B&

# 8. APPLICATION DATA

# (1) Installation of indoor unit

Model DXK21, 24ZTLA-WF R32 REFRIGERANT USED

#### **SAFETY PRECAUTIONS**

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation. If unusual
- uon work in order to protect yourself.

  The precautionary items mentioned below are distinguished into two levels, (AWARNING) and (ACAUTION)

  (AWARNING) Indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.

  (ACAUTION) Indicates a potentially hazardous situation which, if not avoided, can result in personal injury or property damage.

  Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

### **MARNING**

- Be sure to use only for residential purpose.

  If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc... it can malfunction

- etc., it can malfunction.

  Installation must be carried out by the qualified installer completely in accordance with the installation manual.

  Installation by an unqualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.

  Be sure to wear protective goggles and gloves while performing installation work. Improper safety measures can result in personal injury.

  Use the original accessories and the specified components for the installation. Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.

  Do not install the unit near the location where leakage of flammable gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.
- Bo not install the unit near ne location where leakage or trainmaine gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.

  When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage. If refrigerant density exceeds the limit, consult the dealer and install the ventilation system. Otherwise lack of oxygen can occur resulting in serious accident.

  Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.

  Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

  Do not run the unit with removed panels or protections.

  Touching rotating equipment, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.

  This unit is designed specifically for R32.

  Using any other refrigerant can cause unit failure and personal injury.

  Do not vent R32 into atmosphere.

  R32 is a fluorinated greenhouse gas with a Clobal Warming Potential (GWP) = 675.

  Make sure that no air enters the refrigerant circuit when the unit is installed and removed.

  If air enters the refrigerant circuit, the pressure in the refrigerant circuit when the unit is installed and removed.

- Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.

  Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and
- personal injury. Be sure to connect both liquid and gas connecting pipes properly before op-Do not open the liquid and gas service valves before completing piping work, and evacuation.
- If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in
- Be sure to tighten the flare nuts to specified torque using the torque wrench.
  Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.

- During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes.

  If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.

  In the event of refrigerant leakage during installation, be sure to ventilate the working area properly. If the refrigerant comes into contact with naked flames, poisonous gases will be produced.

  Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations. Incorrect installation can cause electric shock, fire or personal injury.

  Make sure that earth leakage breaker and circuit breaker of appropriate capacities are installed.
- pacities are installed.

  Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage.

  Be sure to switch off the power source in the event of installation, mainte-
- nance or service.

  If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.

  Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.
- Loose connections or cable mountings can cause anomalous heat production or fire.

  Do not process, splice or modify the power cable, or share the socket with other power plugs.

  Improper power cable or power plug can cause fire or electric shock due to poor connection, insuf-
- ficient insulation or over-current
- Do not perform any change in protective device or its setup condition yourself. Changing protective device specifications can cause electric shock, fire or burst.

  Be sure to clamp the cables properly so that they do not touch any internal
- component of the unit.

  If cables touch any internal component, it can cause overheating and fire.

  Be sure to install service cover properly.

  Improper installation can cause electric shock or fire due to intrusion of dust or water

- Improper installation can cause electric shock or fire due to intrusion of dust or water.

  Be sure to use the prescribed power and connecting cables for electrical work.

  Using improper cables can cause electric leak or fire.

  This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm.

  Improper electrical work can cause unit failure or personal injury.

  Be sure to connect the power source cable with power source properly.

  Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

  Do not turn ON the wireless LAN communication near automatic control acculaments such as an automatic door or fire alarm device.

- equipment such as an automatic door or fire-alarm device.
  It may cause an accident due to malfunction of equipment.
  Do not turn ON the wireless LAN communication in a hospital, etc. where the use of wireless devices is prohibited.
- It may cause malfunction of medical equipment due to a wireless device.

  Do not turn ON the wireless LAN communication near a person with a cardiac pacemaker or implanted defibrillator.

  It may cause malfunction of a medical device.

# **⚠** CAUTION

(4) Tapping screws (for installation board  $\phi 4 \times 25$ mm)

- Take care when carrying the unit by hand.

  If the unit weight is more than 20 kg, it must be carried by two or more persons.

  Do not carry the unit by the plastic straps. Always use the carry handle.
- Do not install the outdoor unit in a location where insects and small animals can inhabit.
- Insects and small animals can enter the electrical parts and cause damage resulting in fire or per-
- sonal injury. Instruct the user to keep the surroundings clean.

  If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.
- for installation, maintenance and service.

  Insufficient space can result in personal injury due to falling from the height.

  Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.

  It can affect surrounding environment and cause a claim.

  Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere.

  It can cause corrosion of heat exchanger and damage to plastic parts.

  Do not install the unit close to the equipment that generates electromagnetic waves and/or platch parmonic waves.
- waves and/or high-harmonic waves.

  Equipment such as inverters, standby generators, medical high frequency equipment and telecomunication equipment can affect the system, and cause malfunctions and breakdowns.
- The system can also affect medical equipment and telecommunication equipment, and obstruct its
- Do not turn ON the wireless LAN communication near another wireless device, microwave, cordless phone, fax machine, etc. It may cause malfunction of wireless device

- Do not install the unit in the locations where:

  - There are heat sources nearby.

    Unit is directly exposed to rain or sunlight.

    There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.

    Unit is directly exposed to oil mist and steam such as kitchen.
  - Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate. Drain water cannot be discharged properly. TV set or radio receiver is placed within 1 m.

  - Height above sea level is more than 1000 m.

  - It can cause performance degradation, corrosion and damage of components, unit malfunction and fire
- Dispose of all packing materials properly.

  Packing materials contain nails and wood which can cause personal injury.
- Keep the polybag away from children to avoid the risk of suffocation.

- Do not put anything on the outdoor unit.

  Object may fall causing property damage or personal injury.

  Do not touch the aluminum fin of the outdoor unit.

  Aluminium fin temperature is high during heating operation. Touching fin can cause burn.
- Administration in temperature is might owing heating operation. Document in can cause burn.

  Do not touch any refrigerant pipe with your hands when the system is in operation.

  During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).

  Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.


  The isolator should be locked in OFF state in accordance with EN60204-1.


#### 1. ACCESSORIES AND TOOLS Standard accessories (supplied with indoor unit) 1 pc. (5) Wood screws (for remote control holder \$\phi 3.5 \times 16mm) (1) Installation board (6) Batteries [R03 (AAA, Micro) 1.5 V] 2 pcs Remote control 1 pc. (3) Remote control holder (7) Air-cleaning filters 1 pc. **1** pc


7 pcs. (8) Insulation (#486 50 × 100 t3)


	Locally procured parts				
(a)	Sleeve (1 pc.)				
(b)	Sealing plate (1 pc.)				
(c)	Inclination plate (1 pc.)				
(d)	Putty				
(e)	Connecting cable				
(f)	Drain hose (extension hose)				
(g)	Piping cover (for insulation of connection piping)				
(h)	Clamp and screw (for finishing work)				
(i)	Electrical tape				

Tools for installation Work				
Phillips head driver	Pipe cutter			
Knife	Hole core drill (65mm in diameter)			
Saw	Wrench key (Hexagon) [4mm]			
Tape measure	Flaring tool set*			
Torque wrench	Gas leak detector*			
(14.0-62.0 N·m (1.4-6.2 kgf·m))	Pipe bender			
Plier	Flare adjustment gauge			
* Designed specifically for R32 or R410A				










#### 6. FORMING PIPING AND DRAIN HOSE 1. Forming piping right, rear, downward, left, left rear or left downward direction Piping Forming of piping Hold the bottom of the Taping of the exterior Tape only the portion that goes through the wall. Always tape the wiring piping and fix direction before stretching it NOTE Sufficient care must be taken not to damage Cut out the panel smoothly along the line in case of side or bottom piping. and shaping it. with the piping. the panels when connecting pipes. Drain change procedures Remove the screw and drain hose. Remove the drain cap by hand or pliers. Remove the drain cap with was removed at procedure (2) securely using a hexagonal wrench etc. Install the drain hose and screw securely. 4 Downward rear (1) (2) (4) Left de Left hand side piping Right hand side piping Piping in the left rear direction Piping in the right rear direction **↑** CAUTION י Pipina in the left direction Incorrect installation of drain hose and cap can cause water leakage



# 9. CONNECTING PIPING WORK

#### 1. Preparation of connecting pipe

7. DRAINAGE WORK

1.1 Selecting connecting pipe
Select connecting pipe according to the following table.

Gas pipe	φ12.7
Liquid pipe	φ6.35

- Pipe wall thickness must be greater than or equal to 0.8mm.
  Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

- 1.2 Cutting connecting pipe
   (1) Cut the connecting pipe to the required length with pipe cutter.
   (2) Hold the pipe downward and remove the burs. Make sure that no foreign material enters the pipe.
   (3) Cover the connecting pipe ends with the tape.

# 2. Piping work

2.1 Flaring pipe

(1) Take out flare nuts from the operation valves of indoor unit and engage them onto connecting pipes.

(2) Flare the pipes according to table and figure shown below.

Flare dimensions for R32 are different from those for conventional refrigerant.

Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.

	Copper pipe outer diameter	А	
	φ6.35	9.1	
HļI	φ12.7	16.6	



Copper pipe	B [Rigid (clutch) type]		
outer diameter	R32 or R410A	Conventiona	
φ6.35	0-0.5	1.0-1.5	
φ12.7	0-0.5		

2.2 Connecting pipes
(1) Connect pipes on both liquid and gas sides.
(2) Tighten nuts to specified torque shown in the table below

Tightening torque (N·m) Operation valve size (mm) φ6.35 (1/4") 14-18 φ12.7 (1/2")



- · Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant


- 3. Heating and condensation prevention
  (1) Dress the connecting pipes (both liquid and gas pipes) with insulation to prevent it from heating and (1) Dress are Continuing pipes (both injuricant) gas pipes) will insulation to prevent it north meaning and dew condensation.

  Use the heat insulating material which can withstand 120 °C or higher temperature. Make sure that insulation is wrapped lightly around the pipes and no gap is left between them.

  (2) Wrap the refigerant piping of indoor unit with indoor unit heat insulation using tage.

  (3) Wrap the fare-connected plorits (indoor side) with the indoor unit, heat insulation and wrap it with an insulation pad (standard accessory) provided with indoor unit).

  (4) Wrap the connecting pipes, connecting cable and drain hose with the tape.





#### NOTE

Locations where relative humidity exceeds 70 %, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials.

#### **⚠** CAUTION

- Improper insulation can cause condensate(water) formation during cooling operation.
  Condensate can leak or drip causing damage to household property.
  Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

#### 4. Finishing work

- 4. Finishing work.
  (1) Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route.
  (2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly
- should be anchored every 1.5 m or less to isolate the vibration.

  (3) Install the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.



a (0

#### **⚠ WARNING**

- To avoid the risk of fire or explosion, the flared connection must/shall be installed outdoors.
- Reusable mechanical connectors and flared joints are not
- allowed indoors.

# Indoor Flared joint outside for indoor unit

### **⚠** CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.


# 10. HOW TO OPEN, CLOSE, REMOVE AND INSTALL THE AIR INLET PANEL

1. Open
Pull the air inlet panel, place your thumbs on
both sides of the lower part and release hooks,
then pull up the panel until you feel resistance.
(The panel stops at approx. 60° open position)

Hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the hook works.

3. Removing Open the panel by  $90^\circ$  (as shown in the right illustration) and then pull it forward.

A. Installing
Insert the panel arm into the slot on the front
panel from the position shown in right illustration, hold the panel at both ends of lower panlower it downward slowly, then push it slightly until the hook works



# 11. HOW TO REMOVE AND INSTALL THE BOTTOM AND FRONT PANEL

#### 1. Bottom panel

1.1 Removing
(1) Remove the 3 screws (in the cap).
(2) Remove the 2 hooks of left and right side and then bottom panel can be removed.


- 1.2 Installing
  (1) Install the 2 hooks of left and right side.
  (2) Secure the bottom panel with the 3 screws
- (in the cap).

#### 2. Front panel

- 2.1 Removing
  (1) Remove the air inlet panel, the air filters and the bottom panel.
- (2) Remove the 5 screws.
  (3) Remove the 4 upper hooks and then front panel can be removed

#### 2.2 Installing

- (1) Cover the unit with the front panel and fix 4 upper hooks.
  (2) Secure the front panel with the 5 screws.
  (3) Install the bottom panel, the air inlet panel and the air filters.



# 12. INSTALLING REMOTE CONTROL

#### Mount the batteries

- (1) Remove the cover of backside.
  (2) Mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body properly.
  (Fit he poles with the indication marks + & -)
- (3) Set the cover again.

- Do not use new and old batteries together.
   In case the unit is not account. In case the unit is not operated for a long time, take out the batteries
- Installing remote control holder
- signals.
  (2) Fix the holder to pillar or wall with wood
- · Do not mix old and new batteries, or batteries of different types (manganese/alkaline).




### 13. TERMINAL CONNECTION FOR AN INTERFACE

To install wired remote control, Superlink etc., interface kit is needed

- Turn off the power source.
   Remove the air inlet panel, bottom panel and front panel.
   Remove the control cover.
   (Remove the screw.)
- (4) There is a terminal (respectively marked with CNS) on the indoor unit PCB.
  While connecting an interface, connect to the CNS terminal securely with the connection harness supplied with an option "Interface connection kit SC-BIKN2-E" and fasten the connection harness onto the indoor control box with the clamp and screw supplied with

For more details, refer to the user's manual of "Interface connection kit SC-BIKN2-E".



# 14. INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one remote control

#### Setting one remote control

- (1) Remove the cover and batteries.
  (2) Cut the switching line next to the battery with wire cutters.
  (3) Set the batteries and cover again.



- Setting one indoor unit
  (1) Turn off the power source and turn it on after (1) Turn off t 1 minute
- 1 minute.
   (2) Send the signal by pressing the ACL switch on the remote control that was set according to the procedure described on the left side.
   (3) Check that the reception buzzer sound "Peep" is emitted from the indoor unit. Since the signal is sent about 6 seconds after the ACL switch is pressed, point the remote control to the indoor unit for a while.

### NOTE

If no reception buzzer is emitted, restart the setting from the beginning.



# 15. PUMP DOWN WORK

For the environmental protection, be sure to pump down when relocating or disposing of the unit. Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit before the connecting pipes are removed from the unit. When pump down is carried out, forced cooling operation is needed

### Forced cooling operation

- Turn off the power source and turn it on again after 1 minute.
   Press the ON/OFF button continuously for at least 5 seconds. Then operation will start.

For the detail of pump down, refer to the installation manual of outdoor unit.



# 16. INSTALLATION CHECK AND TEST RUN

After finishing the installation work, check the following points again before turning on the power. Conduct a test run and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

Before test run Before test run, check following points.

Power source voltage complies with the rated voltage of air-conditioner.	
Earth leakage breaker and circuit breaker are installed.	
Power cable and connecting cable are securely fixed to the terminal block.	
Both liquid and gas service valves are fully open.	
No gas leaks from the joints of the service valves.	
Indoor and outdoor side pipe joints have been insulated.	
Hole on the wall is completely sealed with putty.	
Drain hose and cap are installed properly.	
Screw of the terminal cover is tightened securely	

Chock following points during toot run.				
Indoor unit receives signal of remote control.				
Air-conditioning operation is normal.				
There is no abnormal noise.				
Water drains out smoothly.				
Display of remote control is normal.				

#### After test run

Explain the operating and maintenance methods to the user according to the user's manual.	
Keep this installation manual together with user's manual.	

#### NOTE

During restart or change in operation mode, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not malfunction.

RWC012A078

Model DXC21, 247TI A-W R32 REFRIGERANT USED

### (2) Installation of outdoor unit

• This installation manual deals with an outdoor unit installation only. For an indoor unit installation, refer to page 25

#### SAFETY PRECAUTIONS

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.
   The precautionary items mentioned below are distinguished into two levels, AWARNING and ACAUTION
   Be sure to confirm no operation problem on the equipment after completing the installation. If unusual noise can be heard during the test run, consult the dealer.
   Be sure to explain the operating methods as well as the maintenance methods of this equipment to the

MARNING Indicates a potentially hazardous situation which, if not avoided, can result in serious con
user according to the user's manual.

Be sure to keep the installation manual together with user's manual at a place where it is easily accessing the control of the user's manual.

- Eastwarming indicates a potentially inactions studied white, it not avoided, call result in serious our sequences such as death or severe injury.

  ACAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal injury or properly damage.

  Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

# **⚠ WARNING**

- Be sure to use only for residential purpose.
- If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc.. it can malfunction

- etc., it can malfunction.

  Installation must be carried out by the qualified installer completely in accordance with the installation manual.

  Installation by an unqualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.

  Be sure to wear protective goggles and gloves while performing installation work. Improper safely measures can result in presonal injury.

  Use the original accessories and the specified components for the installation. Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.

  Do not install the unit near the location where leakage of flammable gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury. sonal injury.
- sonal injury.

  When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISOS149) in the event of leakage. If refrigerant density exceeds the limit, consult the dealer and install the ventilation system. Otherwise lack of oxygen can occur resulting in serious accident.
- Install the unit in a location where unit will remain stable, horizontal and free
- of any vibration transmission.

  Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

  Do not run the unit with removed panels or protections.
- Do not run the unit with removed panels or protections.
   Touching rotating equipment, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.
   This unit is designed specifically for R32.
   Using any other refrigerant can cause unit failure and personal injury.
   Do not vent R32 into atmosphere.
   Pagains designed describerage sequities College Magains Detacted (CMD) = 675.

- R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

  Make sure that no air enters the refrigerant circuit when the unit is installed and removed.
  If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which

   •
- can cause burst and personal injury.

  Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.

  Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and
- Be sure to connect both liquid and gas connecting pipes properly before op-Do not open the liquid and gas service valves before completing piping work, •
- and evacuation.
- If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.

  Be sure to tighten the flare nuts to specified torque using the torque wrench.
- Tightening flare nuts with excess torque can cause burst and refrigerant I

- During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes.

  If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.

  In the event of refrigerant leakage during installation, be sure to ventilate the
- working area properly.

  If the refrigerant comes into contact with naked flames, poisonous gases will be produced.

  Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations.

  Incorrect installation can cause electric shock, fire or personal injury.
- Make sure that earth leakage breaker and circuit breaker of appropriate ca-pacities are installed.

  Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate
- breakers can cause electric shock, personal injury or property damage.

  Be sure to switch off the power source in the event of installation, maintenance or service.

  If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.
- Be sure to tighten the cables securely in terminal block and relieve the ca-bles properly to prevent overloading the terminal blocks.

  Loose connections or cable mountings can cause anomalous heat production or fire.
- Do not process, splice or modify the power cable, or share the socket with
- other power plugs.

  Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.
- Do not perform any change in protective device or its setup condition yourself. Changing protective device specifications can cause electric shock, fire or burst. Be sure to clamp the cables properly so that they do not touch any internal component of the unit.
- If cables touch any internal component, it can cause overheating and fire.
- Be sure to install service cover properly.

  Improper installation can cause electric shock or fire due to intrusion of dust or water.

  Be sure to use the prescribed power and connecting cables for electrical work.
- De sure to use the prescribed power and connecting cables for electrical work. Using improper cables can cause electric leak or fire.

  This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm. Improper electrical work can cause unit failure or personal injury.

  Be sure to connect the power source cable with power source property.
- Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

  Do not turn ON the wireless LAN communication near automatic control equipment such as an automatic door or fire-alarm device.

  It may cause an accident due to malfunction of equipment.
- Do not turn ON the wireless LAN communication in a hospital, etc. where the
- Do not turn On the wireless LAN communication in a nospital, etc. where the use of wireless devices is prohibited. 
  It may cause malfunction of medical equipment due to a wireless device. 
  Do not turn ON the wireless LAN communication near a person with a cardiac pacemaker or implanted defibrillator. 
  It may cause malfunction of a medical device.

### **⚠** CAUTION

- Take care when carrying the unit by hand.
  If the unit weight is more than 20 kg, it must be carried by two or more persons.
  Do not carry the unit by the plastic straps. Always use the carry handle.
  Do not install the outdoor unit in a location where insects and small animals
- can inhabit. Insects and small animals can enter the electrical parts and cause damage resulting in fire or per-
- sonal injury. Instruct the user to keep the surroundings clean.

  If the outdoor unit is installed at height, make sure that there is enough space
- for installation, maintenance and service.

  Insufficient space can result in personal injury due to falling from the height.

  Do not install the unit near the location where neighbours are bothered by
- noise or air generating from the unit.
  It can affect surrounding environment and cause a claim.
- Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere. It can cause corrosion of heat exchanger and damage to plastic parts.
- Do not install the unit close to the equipment that generates electromagnetic \*waves and/or high-harmonic waves.
- Equipment such as inverters, standby generators, medical high frequency equipment and telecommunication equipment can affect the system, and cause malfunctions and breakdowns.

  The system can also affect medical equipment and telecommunication equipment, and obstruct its
- Do not turn ON the wireless LAN communication near another wireless device, microwave, cordless phone, fax machine, etc. It may cause malfunction of wireless device

- Do not install the unit in the locations where:
  - There are heat sources nearby.

    Unit is directly exposed to rain or sunlight.
- Unit is directly exposed to rain or sunlight.

  There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.

  Unit is directly exposed to oil mist and steam such as kitchen.

  Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.

  Drain water cannot be discharged properly.

  Ty set or radio receiver is placed within 1 m.

  Height above sea level is more than 1000 m.

  It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.

- It can cause performance degradation, corrosion and damage of components, unit malfunction and fire
- Dispose of all packing materials properly.

  Packing materials contain nails and wood which can cause personal injury.
- Keep the polybag away from children to avoid the risk of suffocation. Do not put anything on the outdoor unit.
- Object may fall causing property damage or personal injury.

  Do not touch the aluminum fin of the outdoor unit.
- Aluminium fin temperature is high during heating operation. Touching fin can cause burn
- Do not touch any refrigerant pipe with your hands when the system is in operation. During operation the refrigerant pipes the country of the control of the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).

  Install Isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.

  The isolator should be locked in OFF state in accordance with EN60204-1.

### 1. ACCESSORIES AND TOOLS

Standard accessories (Supplied with outdoor unit) Q'ty Locally procured parts Tools for installation work					
(1) Drain grommet	4	(a) Anchor bolt (M10-M12) × 4 pcs.	Plus headed driver	Spanner wrench	Vacuum pump*
	+	(b) Putty	Knife	Torque wrench [14.0-62.0 N•m (1.4-6.2 kgf•m)]	Gauge manifold *
(2) Drain elbow	1	(c) Electrical tape	Saw	Wrench key (Hexagon) [4mm]	Charge hose *
		(d) Connecting pipe	Tono moneyes	Flaring tool set *	Vacuum pump adapter*
(e) Connecting cable Tape measure Flaring tool set * (Anti-reverse flow type)		(Anti-reverse flow type)			
		(f) Power cable	Pipe cutter	Flare adjustment gauge	Gas leak detector *
		(g) Clamp and screw (for finishing work)		· · · · · · · · · · · · · · · · · · ·	*Designed specifically for R32 or R4104

# 2. OUTDOOR UNIT INSTALLATION

### Note as a unit designed for R32

- Note as a unit designed for R32.

  Do not use any refrigerant other than R32. R32 will rise to pressure about 1.6 times higher than that of a conventional refrigerant. A cylinder containing R32 has a light blue indication mark on the top.

  Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to change, which results in performance degradation.

  In charging refrigerant, always take it out from a cylinder in the liquid phase.

  All indoor units must be models designed exclusively for R32. Check connectable indoor unit models in
- a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

- Always carry or move the unit with two or more persons
- The right hand side of the unit as viewed from the front (outlet side) is heavier.

  A person carrying the right hand side must take care of this fact.

A person carrying the left hand side must hold the handle provided on the front panel of the unit with his right hand and the corner column section of the unit with his left hand.



### **△** CAUTION

When a unit is hauled, take care of its gravity center position which is shifted towards right hand side. If the unit is not hauled properly, it can go off balance and fall resulting in serious injury.

#### 2. Selecting the installation location

- Select the suitable installation location where:

  Unit will be stable, horizontal and free of any vibration transmission.

  There is no obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
- There is enough space for service and maintenance of unit.
- Neighbours are not bothered by noise or air generating from the unit. Outlet air of the unit does not blow directly to animals or plants. Drain water can be discharged properly. There is no risk of flammable gas leakage.

- There are no other heat sources nearby
- Unit is not directly exposed to rain or sunlight.
  Unit is not directly exposed to oil mist and steam.
- Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will not generate or accumulate.
- Unit is not directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty at-
- No TV set or radio receiver is placed within 1m.
- · Unit is not affected by electromagnetic waves and/or high-harmonic waves generated by other equipments.


  Strong wind does not blow against the unit outlet.
- · Heavy snowfalls do not occur (If installed, provide proper protection to avoid snow accumulation).

### NOTE

If the unit is installed in the area where there is a possibility of strong wind or snow accumulation, the fol-

#### (1) Location of strong wind

Place the unit with its outlet side facing the wall.
 Place the unit such that the direction of air from








### (2) Location of snow accumulation


- . Install the unit on the base so that the bottom is higher than
- snow cover surface.

  Install the unit under eaves or provide the roof on site



#### 3. Installation space

There must be 1m or larger space between the unit and the wall in at least 1 of the 4 sides. Walls surrounding the unit from 4 sides is not acceptable. The wall height on the outlet side should be 1200mm or less. Refer to the following figure and table for details.



			(111111)
I	II	III	IV
Onen	280	280	180
_			Open
	_		80
250		250	Open
	I Open 100 100 250	Open 280 100 75 100 80	Open         280         280           100         75         Open           100         80         80

#### NOTE


When more than one unit are installed side by side, provide a 250mm or wider interval between them

#### **⚠** CAUTION

When more than one unit are installed in parallel directions, provide sufficient inlet space so that shortcircuiting may not occur.

#### 4. Drain piping work (If necessary)

Carry out drain piping work by using a drain elbow and a drain grommet supplied separately as accessories if condensed water needs to be drained out.
(1) Install drain elbow and drain grommet.
(2) Seal around the drain elbow and drain grommet with putty or adequate caulking material.




Do not put a grommet on this hole This is a supplementary drain hole to discharge drain water, when a large amount of it is gathered.

#### ⚠ CAUTION

Do not use drain elbow and drain grommet if there is a possibility to have several consecutive days of sub zero temperature. (There is a risk of drain water freezing inside and blocking the drain.)

## 5. Installation

- Install the unit on a flat level base.
- While installing the unit, keep space and fix the unit's legs with 4 anchor bolts as shown in the figure below. The protrusion of an anchor bolt from the foundation surface must be kept within 15mm.



### **⚠** CAUTION

- Install the unit properly so that it does not fall over during earthquake, strong wind, etc.

  Make sure that unit is installed on a flat level base. Installing unit on uneven base may result in unit maifunction.

# 3. PREPARATION FOR WORK 1. Removing service cover 2. Removing terminal cover Remove the screw. Slide service cover downwards and remove it. Remove the screw and take out terminal cover

### 4. CONNECTING PIPING WORK

#### 1. Restrictions on unit installation

Abide by the following restrictions on unit installation Improper installation can cause compressor failure or performance degradation

	Dimensional restrictions	
Connecting pipe length(L)	30m or less	
Elevation difference between indoor and outdoor units(H)*	20m or less	

\* Outdoor unit installation position can be higher as well as lower than the indoor unit installation position.

### 2. Preparation of connecting pipe

2.1 Selecting connecting pipe
Select connecting pipe according to the following table.

Gas pipe	φ12.7
Liquid pipe	φ6.35


- Pipe wall thickness must be greater than or equal to 0.8mm.
  Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

If it is required to reuse the existing connecting pipe system, refer to 5. UTILIZATION OF EXISTING PIPE.

#### 2.2 Cutting connecting pipe

- (1) Out the connecting pipe to the required length with pipe cutter.
  (2) Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.
  (3) Cover the connecting pipe ends with the tape.

Check that both liquid and gas service valves are fully closed. Carry out the piping work with service valves fully closed.



#### Flaring pipe

3.1 Flaring pipe
(1) Take out flare nuts from the service valves of outdoor unit and engage them onto connecting pipes.
(2) Flare the pipes according to table and figure shown below.
Flare dimensions for R32 are different from those for conventional refrigerant.
Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.





m	Copper pipe	B [Rigid (clutch) type]		
	outer diameter	R32 or R410A	Conventional	
	φ6.35	0-0.5	1.0-1.5	
÷.	φ12.7	0-0.5	1.0-1.5	

3.2 Connecting pipes
(1) Connect pipes on both liquid and gas sides
(2) Tighton puts to appoint to require the property of the

(2) righten hats to specified torque shown in the table belo		
Service valve size (mm)	Tightening torque (N·m)	
φ6.35 (1/4")	14-18	
φ12.7 (1/2")	49-61	

5. UTILIZATION OF EXISTING PIPE



Do not hold the valve cap area with a spanner

#### **⚠** CAUTION

Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.
 Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

- 4. Evacuation
- (1) Connect vacuum pump to gauge manifold. Connect charge hose of gauge manifold to service port of outdoor unit.
- (2) Run the vacuum pump for at least one hour after the vacuum gauge shows -0.1 MPa (-76 cm Hg).
- (2) Nut nie Vaculum pump in at iestes trie flord ander in le vaculum gauge snows ... nier a (-10 cm ng).

  (3) Confirm that the vaculum gauge indicator does not rise even if the system is left for 15 minutes or more. Vaculum gauge indicator will rise if the system has moisture left inside or has a leakage point. Check the system for the leakage point. If leakage point is found, repair it and return to (1) again.

  (4) Close the Handle Lo and stop the vacuum pump.

  Keep this state for a few minutes to make sure that the compound pressure gauge pointer does not
- swing back.
- (5) Remove valve caps from liquid service valve and gas service valve.
- (6) Turn the liquid service valve's rod 90 degree counterclockwise with a hexagonal wrench key to open
- valve.


  Close it after 5 seconds, and check for gas leakage.
  Using soapy water, check for gas leakage from indoor unit's flare and outdoor unit's flare and valve rods.

  Wipe off all the water after completing the check.

  (7) Disconnect charging hose from gas service valve's service port and fully open liquid and gas service valves. (Do not attempt to turn valve rod beyond its stop.).

  (8) Tighten service valve caps and service port cap to the specified torque shown in the table below.

Service valve	size (mm)	Service valve ca torque (I		Service port cap tightening torque (N·m)
φ6.35 (1	/4")	20-3	0	10-12
φ12.7 (1	/2")	25-3	5	10-12



#### **⚠** CAUTION

 $\label{thm:continuous} \mbox{To prevent vacuum pump oil from entering into the refrigerant system, use a counterflow prevention adapter.}$ 

#### 5. Additional refrigerant charge

Additional refrigerant charge is required only when connecting pipe length exceeds 15m

5.1 Calculating additional refrigerant charge
Additional refrigerant charge can be calculated using the formula given below.
Additional refrigerant charge (g) = { Connecting pipe length (m) – Factory charged length 15 (m) } x 20 (g/m)

### NOTE

· If additional refrigerant charge calculation result is negative, there is no need to remove the refrigerant. If refrigerant recharge is required for the unit with connecting pipe length 15m or shorter, charge the factory charged amount as shown in the table below.

The factory refrigerant charge amount(kg)	1.20
The maximum refrigerant charge amount(kg)	1.50

- 5.2 Charging refrigerant

  (1) Charge the R32 refrigerant in liquid phase from service port with both liquid and gas service valves shut. Since R32 refrigerant must be charged in the liquid phase, make sure that refrigerant is discharged from the cylinder in the liquid phase all the time.


  (2) When it is difficult to charge a required refrigerant amount, fully open both liquid and gas service valves and charge refrigerant, while running the unit in the cooling mode. When refrigerant is charged with the unit being run, complete the charge operation within 30 minutes.

  (3) Write the additional refrigerant charge calculated from the connecting pipe length on the label attached on the service cover.

### **⚠** CAUTION

Running the unit with an insufficient quantity of refrigerant for a long time can cause unit malfunction. Do not charge more than the maximum refrigerant amount. It can cause unit malfunction

# (1) Check whether an existing pipe system is reusable or not by using the following flow chart.



### NOTE

Consult with our distributor in the area, if you need to recover refrigerant and charge it again.

- (2) Clean the existing pipe system according to the procedure given below.
  (a) Carry out forced cooling operation of existing unit for 30 minutes.
  For 'Forced cooling operation' refer to the indoor unit installation manual.
  (b) Stop the indoor fan and carry out forced cooling operation for 3 minutes (Liquid return).
- (c) Close the liquid service valve of the outdoor unit and carry out pump down operation (Refer to 6. PUMP DOWN)
- (d)Blow with nitrogen gas. If discolored refrigeration oil or any foreign matter is discharged by the blow, wash the pipe system or install a new pipe system. Remove the flare nuts from the existing pipe system. Go back to 4.CONNECTING PIPING WORK and proceed to step 2.2 Cutting connecting pipe.

#### *∧* CAUTION

- Do not use the old flare nuts (of existing unit). Make sure that the flare nuts supplied with the (new) outdoor unit are used.
   If the flared / compression connection to the indoor unit is located inside the house / room then this pipework can! be reused.

- th the existing piping is specified as liquid pipe  $\phi$ 9.52 or gas pipe  $\phi$ 12.7, refer to the following


<Table of pipe size restrictions>

Additional charge amount per meter of pipe		0.054 kg/m
Pipe size	Liquid pipe	φ9.52
	Gas pipe	φ12.7
Maximum one-way pipe length		10
Length covered without additional charge		5

Additional charge amount (kg) = {Main pipe length (m) - Length covered without additional charge shown in the table (m)} X Additional charge amount per meter of pipe shown in the table (kg/m)

### 6. PUMP DOWN

- (1) Connect charge hose of gauge manifold to service port of outdoor unit.
  (2) Close the liquid service valve with hexagonal wrench key.
  (3) Fully open the gas service valve with hexagonal wrench key.
  (4) Carry out forced cooling operation (For forced cooling operation procedure, refer to indoor unit installation
- manual). (5) When the low pressure gauge becomes 0.01 MPa, close the gas service valve and stop forced cooling operation.



# 7. ELECTRICAL WIRING WORK

#### **⚠ WARNING**

- Nake sure that all the electrical work is carried out in accordance with the national or regional electrical standards.

  Nake sure that the earth leakage breaker and circuit breaker of appropriate capacities are installed (Refer to the table given below).

  Do not turn on the power until the electrical work is completed.

  Do not turn on condensive capacitor for power factor improvement under any circumstances. (It does not improve power factor. Moreover, it can cause an abnormal overheat accident).

- SRC-ZTLA-W and DXC-ZTLA-W complies with the DRED (Demand Response Enabling Devices) standard AS/NZS4755.3.1 and supports demand response modes 1, 2, and 3 (DRM1, 2, and 3). Since the airconditioner limits the electric power or energy by receiving the DRED input stignal, the sense of coding operation or heating operation may deteriorate over time. The outdoor unit of this air-conditioner is equipped with a terminal block for DRED input and supports ELV (Extra-Low Voltage) complying with AS/NZS60335.1.

### Breaker specifications

Phase	Earth leakage breaker	Circuit breaker
Single phase	Leakage current: 30 mA, 0.1sec or less	Over current: 20 A

#### Main fuse specification

Specification	Parts No.	Code on LABEL, WIRING
250 V 20 A	SSA564A136A	F4

#### 1. Preparing cable

1. Preparing cable
1. Selecting cable
Select the power source cable and connecting cable in accordance with the specifications mentioned below.

(a) Power source cable
3 cores\* 2.5mm² or more, conformed with 60245 IEC57
When selecting the power source cable length, make sure that voltage drop is less than 2 %.
If the wire length gets longer, increase the wire diameter.

(b) Connecting cable
4 cores\* 1.5mm², conformed with 60245 IEC57
1 Earth wire is included (Yellow/Green).


(2) Arrange each wire length as shown below.
Make sure that each wire is stribued 10mm from the end.

Make sure that each wire is stripped 10mm from the end.



(3) Attach round crimp-type terminal to each wire as shown in the be

Select the size of round crimp-type terminal after considering the specifications of terminal block and wire diameter



#### **⚠** CAUTION

Power source cable and connecting cable must conform to the specifications mentioned in the manual. Using cables with wrong specifications may result in unit malfunction.

#### 2. Connecting cable

- 2. Connecting cable

  (1) Remove the service cover and the terminal cover.

  (2) Connect the cables according to the instructions and figures given below.

  (a) Connect the earth wire of power source cable.

  An earth wire must be connected before connecting the other wires of power source cable.

  Keep the earth wire longer than the remaining two wires of power source cable.

  (b) Connect the remaining two wires (N and L) of power source cable.

  (c) Connect the wires of connecting cable. Make sure that for each wire, outdoor and indoor side terminal numbers match.


  (d) Connecting cable between outdoor unit and DRED shall be double insulation layer, polychloroprene sheathed (>50 V) with size 4 x (0.5mm² to 2.0mm²) cable or flexible cord, where the aximum allowable length is 30 m.


  (3) Fasten the cables properly with cable clamps so that no external force may work on terminal connections.

Taster the Cables properly with cable damps so that he external notes may work on terminal connections.

Moreover, make sure that cables do not touch the piping, etc. When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection.

#### <Circuit diagram>





# 8. FINISHING WORK

#### 1. Heating and condensation prevention

- (1) Dress the connecting pipes (both liquid) and gas pipes) with insulation to prevent it from heating and dew condensation.


  Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that insulation is wrapped tightly around the pipes and no gap is left between them.

  (2) Wrap the refigerant piping of indoor unit theat insulation using tape.

  (3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an of installed property, resulting in unit malfunction and failure.

- insulation pad (standard accessory provided with indoor unit).

  (4) Wrap the connecting pipes, connecting cable and drain hose with the tape




# NOTE

Locations where relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials

- Improper insulation can cause condensate (water) formation during cooling operation.
  Condensate can leak or drip causing damage to household property.
  Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating
- operation. It can cause cable deterioration and personal injury.

#### 2. Finishing work



Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.

## 9. INSTALLATION TEST CHECK POINTS

After finishing the installation work, check the following points again before turning on the power

Conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates proper

Power source voltage complies with the rated voltage of air-conditioner.	
Earth leakage breaker and circuit breaker are installed.	
Power cable and connecting cable are securely fixed to the terminal block.	
Both liquid and gas service valves are fully open.	

No gas leaks from the joints of the service valves Indoor and outdoor side pipe joints have been insulated Drain hose (if installed) is fixed properly. Screw of the terminal cover and the service cover are tightened properly.

# (3) Safety precautions in handling air-conditioners with flammable refrigerant

RSA012A090D 🙈

# R32 REFRIGERANT USED



This equipment uses flammable refrigerants. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.



There is information included in the user's manual and/or installation manual



The user's manual should be read carefully



A service personnel should be handing this equipment with reference to the installation manual.

- This safety precaution sheet is for R32 refrigerant. If you want to know the type of refrigerant in the unit, check the label attached to the outdoor unit.
- The precautionary items mentioned below are distinguished into two levels, A WARNING and A CAUTION

⚠ WARNING: Wrong installation would cause serious consequences such as injuries or death.

A CAUTION: Wrong installation might cause serious consequences depending on circumstances.

### ⚠ WARNING

- Strict compliance of the domestic laws must be
- observed when disposing the appliance. Do not use means to accelerate the defrost operation process or to clean, other than those recommended by the manufacturer.
- · The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater)
- · Do not pierce or burn
- Be aware that refrigerants may not contain an
- The ducts connected to an appliance shall not contain a potential ignition source.

# **⚠** CAUTION

### 1. General

- That the installation of pipe-work shall be kept to a
- That pipe-work shall be protected from physical damage
- That compliance with national gas regulations shall be observed.
- That mechanical connections shall be accessible for maintenance purposes
- Keep any required ventilation openings clear of obstruction.
- Servicing shall be performed only as recommended by the manufacture
- Equipment piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service.
- Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping
- Protection devices, piping and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris.
- Provision shall be made for expansion and contraction of long runs of piping.
- Piping in refrigerating systems shall be so designed and installed to minimize the likelihood hydraulic shock damaging the system.
- The indoor equipment and pipes shall be securely mounted and guarded such that accidental rupture of equipment cannot occur from such events as moving furniture or reconstruction activities
- Instructions for wiring to external zoning dampers and/or mechanical ventilation, to ensure that upon detection of a leak, the zoning dampers are driven fully open and additional mechanical ventilation is
- For appliances using A2L refrigerants, connected via an air duct system to one or more rooms, the supply and return air shall be directly ducted to the space. Open areas such as false ceilings shall not be used as a return air duct.
- The following information requirements apply for enhanced tightness refrigerating systems using A2L refrigerants.
- Where safety shut off valves are specified, the minimum room area may be determined based on the maximum amount of refrigerant that can be leaked as determined in GG.12.2. (IEC 60335-2-40:2018)
- Where safety shut off valves are specified, the location of the valve in the refrigerating syste relative to the occupied spaces shall be as described in GG.12.1.(IEC 60335-2-40:2018)

### (2. Unventilated areas

- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- If the refrigerant charge amount in the system is ≥1.84 kg, an unventilated area where the appliance is installed shall be so constructed that should any refrigerant leak, it will not stagnate so as to create a fire or explosion hazard.

#### (3. Qualification of workers

The staff in servicing operations must hold the national qualification or other relevant qualifications.

### 4. Information on servicing

- 4.1 Checks to the area
- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.
- For repair to the refrigerating system, 4.2 to 4.6 shall be completed prior to conducting work on the system.
- 4.2 Work procedure
- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being
- 4.3 General work area
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- Work in confined spaces shall be avoided
- 4.4 Checking for presence of refrigerant
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- 4.5 Presence of fire extinguisher
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area

- 4.6 No ignition sources
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.
- 4.7 Ventilated area
- . Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- 4.8 Checks to the refrigerating equipment
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to
- installations using flammable refrigerants:
- the actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used. the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

#### **⚠** CAUTION

- 4.9 Checks to electrical devices
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- This shall be reported to the owner of the equipment so all parties are advised
- Initial safety checks shall include:
- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system:
- that there is continuity of earth bonding.

### ( 5. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
- This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that the apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

### (6. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
  The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

### 7. Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

#### (8. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.
- Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

Examples of leak detection fluids are

- bubble method,
- fluorescent method agents
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak
- Removal of refrigerant shall be according to Item 9.

### 9. Removal and evacuation

- · When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to: remove refrigerant;
- purge the circuit with inert gas (option for A2L); evacuate (option for A2L);
- purge with inert gas (option for A2L);
- open the circuit by cutting or brazing.
   The refrigerant charge shall be recovered into the
- correct recovery cylinders. For appliances containing flammable refrigerants other than A2L refrigerants, the system shall be purged with oxygen-free nitrogen to render the
- appliance safe for flammable refrigerants. This process may need to be repeated several times
- Compressed air or oxygen shall not be used for purging refrigerant systems.
- For appliances containing flammable refrigerants, other than A2L refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system.
- When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is

#### ( 10. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in
- Cylinders shall be kept in an appropriate position according to the instructions
- Ensure that the refrigerating system is earthed
- prior to charging the system with refrigerant.

  Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigerating system
- Prior to recharging the system, it shall be pressuretested with the appropriate purging gas
- The system shall be leak-tested on completion of charging but prior to commissioning
- A follow up leak test shall be carried out prior to leaving the site.

### (11. Decommissioning)

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant.
- It is essential that electrical power is available before the task is commenced.
- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
- all personal protective equipment is available and being used correctly;
  the recovery process is supervised at all times by
- a competent person;
- recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders. (No more than 80 %volume liquid charge).
  i) Do not exceed the maximum working pressure of
- the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.

### 12. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed.
- For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

### **A** CAUTION

# 13. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge is available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
   Cylinders shall be complete with pressure relief
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants.

- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
- Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
   Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

# 14. Other safety precautions

- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts.
- Flammable refrigerant used, refrigerant tubing protected or enclosed to avoid mechanical damage (IEC/EN 60335-2-40).
- Tubing protected to extent that it will not be handled or used for carrying during moving of product (IEC/EN 60335-2-40).
- Flammable refrigerant used, low temperature solder alloys, such as lead/tin alloys, not acceptable for pipe connections (IEC/EN 60335-2-40).
- Do not use flare nut indoor which is locally procured.

# Selection of installation location for the indoor unit

• Minimum installation area for indoor unit

# **⚠** CAUTION

The indoor unit shall be installed in a room with minimum installation area or more according to the refrigerant charge amount (factory refrigerant charge + additional refrigerant charge).

For factory refrigerant charge, refer to the outdoor unit label model name or installation sheet.

- For additional refrigerant charge, refer to the outdoor unit installation sheet.
- If the refrigerant charge amount in the system is < 1.84 kg, there are no additional minimum floor area requirements.
- If the refrigerant charge amount in the system is  $\geq$  1.84 kg, you need to comply with additional minimum floor area requirements as described in the following table.
- For further details regarding the installation location of indoor unit, refer to technical manual.




Figure 1. Minimum installation area (A min) graph

Table 1. Minimum installation area (A min) table

	Minimum installation area [m²]		
Refrigerant charge amount [kg]	Wall mounted units H=1.8 m	Ceiling mounted units H=2.2 m	Floor standing units H=0.6 m*
1.00			
1.10			
1.20			
1.30			
1.40	No requirements		
1.50			
1.60			
1.70			
1.80			
1.84	4.44	3.64	28.82
1.90	4.59	3.76	30.73
2.00	4.83	3.95	34.05
2.10	5.07	4.15	37.54
2.20	5.31	4.35	41.20
2.30	5.55	4.55	45.03
2.40	5.80	4.74	49.03
2.50	6.04	4.94	53.20
2.60	6.40	5.14	57.54
2.70	6.90	5.34	62.05
2.80	7.42	5.53	66.73
2.90	7.96	5.73	71.58

	Minimum installation area [m²]		
Refrigerant charge	Wall mounted	Ceiling mounted	Floor standing
amount [kg]	units	units	units
	H=1.8 m	H=2.2 m	H=0.6 m*
3.00	8.52	5.93	76.60
3.10	9.09	6.12	81.79
3.20	9.69	6.49	87.16
3.30	10.30	6.90	92.69
3.40	10.94	7.32	98.39
3.50	11.59	7.76	104.26
3.60	12.26	8.21	110.31
3.70	12.95	8.67	116.52
3.80	13.66	9.15	122.90
3.90	14.39	9.63	129.45
4.00	15.14	10.13	136.18
4.10	15.90	10.65	143.07
4.20	16.69	11.17	150.14
4.30	17.49	11.71	157.37
4.40	18.31	12.26	164.77
4.50	19.15	12.82	172.35
4.60	20.01	13.40	180.09
4.70	20.89	13.99	188.01
4.80	21.79	14.59	196.09
4.90	22.71	15.20	204.35
5.00	23.65	15.83	212.78
It to IEC 6033E 3 40:3040 Clause CC 3			

\*For floor standing units, the value of installation height (H) is considered 0.6 m to comply to IEC 60335-2-40:2018 Clause GG.2.